

A5
LETTER



Price List of Parts
for
Brush Runabouts
Models D, E, F and Liberty

Maxwell Motor Sales Corporation, Newcastle, Ind.

Price List of Parts for
Brush Runabouts

Models D, E, F and Liberty


Read Carefully Instructions for Ordering Parts

Maxwell Motor Sales Corporation, Newcastle, Ind.

Service Stations

13th and East Ave., Long Island City, N.Y.

675 Golden Gate Ave., San Francisco, Cal.



Map showing strategic location of Parts Plant of Maxwell Motor Company at Newcastle, Indiana, which is within a few miles of the center of population of the United States and less than twelve hours' shipping distance from over 50% of old customers. This plant is acknowledged to be the best plant in the world devoted to the making of replacement parts for past models.

An Investment of \$1,750,000 in Plant and Stock of Parts for Service to Old Customers

Read the Maxwell Plan of Service to Owners of Brush Runabouts

While not legally obligated, the Maxwell Motor Company does feel morally obligated to every owner of a car made by any of the concerns whose plants and equipment it has acquired. In brief, the companies that formerly made the Maxwell-Briscoe, Stoddard-Dayton, Columbia, Everitt, Sampson, Brush and Courier Cars.

We believe our plan for taking care of former customers is the most comprehensive, the most expeditious, and has proven altogether the most satisfactory to owners that has yet been devised by any concern.

All special tools and jigs for the making of interchangeable replacement parts were carefully conserved and installed in the plant formerly known as Maxwell-Briscoe plant at Newcastle, Indiana.

This plant occupies a unique location—it happens to be in the city which, according to the last U. S. census, is almost the exact center of population. The plant and equipment represent an investment of one and three-quarters millions dollars—and is devoted exclusively to the making of repair and replacement parts for former models.

Study the map. Its center is Newcastle, Indiana. Not the center of the United States, but of greater importance—the center of population and the center of ownership of Maxwell, Brush, Courier, Everitt, Columbia and Stoddard-Dayton cars and Alden-Sampson trucks.

Follow the three circles. All cities and towns on the line, and inside the greater circle, are approximately 24 to 36 hours express shipping distance from our Newcastle Parts Factory.

Those points on the line and inside the intermediate circle are only 12 to 18 hours distance, and those points on the line and inside the inner circle are 6 to 12 hours or less distant from the central supply point—Newcastle, Indiana.

That you may the better appreciate what this means in prompt service in emergency cases, please note that of the more than 122,000 owners of these cars, 37,606 live within the outer (24-hour) circle; 84,494 (or over 70% of owners) live within the 12-hour circle, and 60,079 (or over 50% of all owners) are within 6 hours of our central supply point.

Now, consider for a moment, that in order to give quick service to the extreme Eastern and Western Sections, we have Service Stations in Greater New York (Long Island City) and San Francisco. Cal. All owners living in Eastern States are supplied from the Maxwell Motor Sales Corporation (13th and East Ave.), Long Island City,

N. Y.; those living between the Alleghanies and the Rockies, from the Maxwell Motor Sales Corporation, Newcastle, Ind.; and all owners west of the Rockies—all Pacific Coast—are supplied from the Maxwell Motor Sales Corporation (675 Golden Gate Ave.), San Francisco, California.

These Service Stations carry such parts as are in most general demand and from which you or your dealer or repair man can almost instantly obtain any desired part. You will see that old customers are taken care of in a manner never before attempted in this business.

When it is considered that one building 60 ft. wide and 722 ft. long and three stories high is devoted exclusively to the storage of these replacement parts, some idea may be had of the task involved.

In this building are 45,000 separate bins, each containing a separate automobile part. In addition to these are hundreds of racks—literally miles of racks—for the storing of radiators, mud guards, frames, axles, etc., etc., etc.

It is interesting to know that the majority of the parts come within the 21-lb. weight limit, and are therefore sent by Parcels Post. This is a great saving, especially for those owners who live in rural districts, and who, were the parts sent by express, would have to make an extra trip to town and wait an extra day for the part. In addition to the large number of parts sent by Parcels Post, something over 25 tons per week go by express, and such large parts as axles, etc., as go by freight, make up another 20 tons per week.

Contrary to the usual practice, the Maxwell Motor Company has decided to *recognize any dealer*, no matter what line he handles, and to give him the regular dealer's discount on these parts.

The reasons for doing this are two: First, a great many dealers who formerly handled Maxwell-Briscoe, Stoddard-Dayton, Everitt, or the other lines, do not now handle Maxwell cars—and vice versa. Obviously it would be unfair to an owner, and also we think unfair to those former dealers, to insist that an owner get parts only through our present dealers.

Second, in establishing the Service Factory and Stations, we have done so entirely for the owner's convenience, and we wish to still further help him by making it possible for him to get any part he wants for his car from his nearest dealer, regardless of whether that dealer handles the present Maxwell line or not. We believe that dealers generally will appreciate this, and we are sure the owners will.

Instructions for Ordering Parts

Price, Terms and Conditions Subject to Change

Without Notice

How to Order.

The Maxwell Motor Sales Corporation cannot hold itself responsible for errors and delays through failure to comply with the following instructions, nor will it be responsible for errors which may occur as the result of incorrectly written or incorrectly transmitted telegraph or telephone orders.

When ordering parts give:

- The name of the Model (such as Brush Model D-E-F or Liberty and state if runabout or roadster);
- the car number (which can be found on the name plate on the dash);
- the motor number (which will be found on top of cylinder casting on left);
- the part number;
- the name of part (if painted, state color, and when ordering, state if part is right or left, front or rear);
- also state how many of each part are wanted;
- if parts are for car with sixty-inch thread, state same in your order.

Write your orders for parts on a separate sheet of paper from your letter, preferably on the blanks furnished by the Company; leave nothing to be inferred. State definitely what is wanted, and address all correspondence to the Company and not to individuals.

With every order give shipping directions, each time giving the name of county, as well as town and state.

If in doubt as to the number or name of part, send us the old part or parts; carrying charges prepaid and be careful to tag each part with your firm name, your address, and the car number, then send letter stating fully when and how you are sending the old material, and give explicit shipping instructions for the return of the new goods.

REMITTANCES.

Terms: Strictly cash with order, except to regularly appointed dealers having a deposit with the company. We open no accounts with others.

Send remittances with your order, otherwise goods will be held for remittance or sent C. O. D., at our option. When parts are ordered shipped by mail, remittance must be sufficient to cover postage also. If remittance is more than sufficient, excess will be refunded. Remittances should be made in New York or Chicago exchange, postoffice or express money order. Make all money orders or drafts payable to the Maxwell Motor Sales Corporation.

IMPORTANT.

Be sure to prepay carrying charges in all cases. Our Receiving Department refuses to accept shipments on which charges have not been prepaid.

REPAIRS.

Repairs made on cars or parts of cars in our repair shop must be paid for in cash, certified check, or New York or Chicago draft upon delivery of such repair cars or parts to their owners or their representatives. Personal checks cannot be accepted. Under no circumstances will accounts be opened for repair work.

These Suggestions Will Save You Money

When returning parts to the factory, bill of lading should be made out showing the contents of boxes or crates under their proper classification.

For Example

If returning fenders bill them as "Crate of Auto Fenders."

Springs as "Elliptic Auto Springs."

Gear parts as "Metal Auto Gear Parts."

Motors as "Gasoline Engines."

State also the number of boxes, bundles or crates used in making shipment.

It's to your own interest, as you have to pay transportation charges, to have your bills of lading correctly made out—then you are sure of getting the lowest freight or express rates.

PRICE LIST OF BRUSH PARTS

Model "E" Parts

All other parts not listed below are either regular model "D" or are interchangeable with them.

MODEL E PARTS NOT INTERCHANGEABLE ON "D", "F" AND "LIBERTY" CARS.

Part No.	Price Each	DESCRIPTION	No. Per Car
BODY AND FRAME.			
2190-D	\$30.00	Radiator	1
2101-B	2.40	Steering Tie Rod Tubing	1
2109-B	2.64	Steering Tie Rod Tubing (wide tread)	1
2102-D	.42	Steering Tie Rod Yoke (R. H.)	1
2103-D	.42	Steering Tie Rod Yoke (L. H.)	1
5/16 x 1	.06	Steering Tie Rod Yoke (L. H.)	1
2100-B	3.36	Steering Tie Rod Comp.	2
2100-C	3.60	Steering Tie Rod Comp. (wide tread)	1
1484-C	7.20	Steering Knuckle and Spindle	1
1481-D	4.80	Steering Knuckle Arm (R. H.)	2
710-B	3.00	Steering Knuckle Arm (L. H.)	1
	4.80	Steering Knuckle Comp. (R. H.)	1
	3.90	Steering Knuckle Comp. (L. H.)	1
2454-D	6.00	Sprocket Wheel (58 x 1/2)	1
			2
MOTOR PARTS.			
2150D			
1206-D	15.60	Cylinder	1
2151-B	.05	Cylinder Gasket	1
2171-B	.48	Valve Cap Exhaust	1
2172-B	.60	Valve Cap Intake	1
2173-A	.06	Valve Cap Gasket	1
2174-B	.96	Valve Pusher	2
2176-B	.12	Water Inlet	2
	.10	Water Hose Clamps	1
	.30	Water Inlet Hose	4
1203E-E	22.20	Crank Case	1
1207-C	12.00	Fly Wheel	1

Order parts for repairs or renewals by number, and name in full and give the number of your motor, which will be found stamped immediately on top of the cylinder.

Model "F" Parts

MODEL "F" PARTS NOT INTERCHANGEABLE ON "D" AND "E" CARS.

BRAKES.

Part No.	Price Each	DESCRIPTION	No. Per Car
2124-B	\$.06	Pull Rod, Short.....	2
2118-B	.24	Pull Rod Link.....	2
3/16 x 13/8	.05	Pull Rod Link Cotter.....	2
2121-B	.66	Brake Rod Shaft.....	1
2122-B	.72	Brake Rod Shaft (W. T.).....	1

CARBURETOR.

2130-D	7.80	Gasoline Tank Front.....	1
	10.50	Carburetor, Kingston	1

ENGINE.

2138-B	.36	Breather Body (Assemb.).....	1
2142-B	.24	Breather Cap Comp.....	1
2139-B	.12	Breather Stand Pipe.....	1
RM-5004	.05	Breather Stand Pipe Ball.....	1
2466-A	.06	Breather Stand Pipe Bushing.....	1
2467-A	.06	Breather Stand Pipe Pin.....	1
2148-B	1.44	Cam Gear	1
2147-C	4.80	Connecting Rod	1
2144E-F	22.20	Crank Case	1
2178-D	14.40	Crank Shaft	1
2150-D	15.60	Cylinder	1
2153-B	1.20	Cylinder Head	1
2154	.30	Cylinder Priming Cock.....	1
2171-B	.48	Valve Cap, plain.....	1
2172-B	.60	Valve Cap, threaded.....	1
2160-D	12.00	Fly Wheel	1
2177-B	.12	Fly Wheel Key.....	1
2163-A	.06	Fly Wheel Stud.....	3

Be sure to put your name and motor number on parts returned to factory, and prepay charges.

PRICE LIST OF BRUSH PARTS

Part No.	Price Each	DESCRIPTION	ENGINE.	No. Per Car
3/8 x 24	\$.06	Fly Wheel Stud Nut.....		3
3/8	.05	Fly Wheel Stud Nut Lock Washer.....		3
2157-C	4.80	Piston		1
2158-A	.72	Piston Pin		1
2140-A	.06	Piston Pin Screw.....		1
2149-B	.01	Piston Pin Screw Wire.....		1
2169-B	.48	Piston Ring		4
1 3/4 x 4 1/4	.10	Water Hose Inlet.....		1
1 3/4 x 5 1/4	.25	Water Hose Outlet.....		1
2170-D	1.50	Starting Crank Bracket.....		1
FRAME.				
2112-D	5.40	Dash		1
68-D	.25	Wire—Primary Batt—Ground		1
68-D	.25	Wire—Primary Batt—Coil		1
54-D	.25	Wire—Primary Coil Comm.		1
47-D	.50	Wire—Secondary Coil Plug.....		1
	12.00	Coil Complete—J. B.		1
2220-D	6.00	Fender Front—Right		1
2221	6.00	Fender Front—Left		1
2222-D	5.40	Fender Rear—Right		1
2223	5.40	Fender Rear—Left		1
2199-D	30.00	Radiator (St. & F26)		1
1847-C	1.75	Spring—Heavy		4
1848-D	.90	Spring Bracket, R. H.—Heavy.....		2
1849-D	.90	Spring Bracket, L. H.		2
2240-D	4.80	Lubricator—Comp.		1
TRANSMISSION.				
2396-D	6.00	Universal Joint Assembly.....		1
2397	.18	Universal Joint Boot.....		2
2398-B	.12	Universal Joint Boot Clamp.....		2
2399-A	.05	Universal Joint Boot Wire.....		2
2400-B	.12	Universal Joint Cover.....		2
2401-D	2.40	Universal Joint Coupling.....		1
2402-A	.12	Universal Joint Coupling Bolt.....		3

Order parts for repairs or renewals by number, and name in full and give the number of your motor, which will be found stamped immediately on top of the cylinder.

MODELS "D", "E", "F" AND "LIBERTY"

TRANSMISSION.

Part No.	Price Each	DESCRIPTION	No. Per Car
3/8 x 24	\$.06	Universal Joint Coupling Bolt Nut.....	3
3/8	.03	Universal Joint Coupling Bolt Nut L.....	3
2403-A	.06	Universal Joint Coupling Set Screw.....	1
2404-A	.54	Universal Joint Slide Block.....	4
2405-B	1.80	Universal Joint Socket.....	2
EN5147	.05	Universal Joint Pipe Plug.....	2
2406-A	.06	Universal Joint Spring.....	2
1328-A	.12	Universal Joint Coupling Key.....	1
2407-A	.06	Universal Joint Boot Lacing.....	2
2395-B	.18	High Speed Spring.....	1
2452-D	5.40	Wheel Sprocket (50 x 1/2).....	2
2408-C	2.70	Coupling Shaft.....	1
2409-A	.60	Coupling Shaft Pin.....	2
2406-A	.12	Coupling Shaft Spring.....	1

"Liberty" Model Parts

LIBERTY PARTS—NOT INTERCHANGEABLE ON MODEL D.-E.-F. CARS.

ENGINE.

2144E-L	\$14.40 22.20	Crank Case (Cast Iron), No. 2144E-L.....	1
---------	-----------------------------	--	---

FRAME.

2.40	Cushion.....	2
2.40	Fender—Right Front.....	1
2.40	Fender—Left Front.....	1
1.80	Fender—Right Rear.....	1
1.80	Fender—Left Rear.....	1
1.08	Fender Iron—Upper—Front and Rear.....	4
.84	Fender Iron—Lower—R. F.....	1
.84	Fender Iron—Lower—L. F.....	1
.84	Fender Iron—Lower—R. R.....	1
.84	Fender Iron—Lower—L. R.....	1

Be sure to put your name and motor number on parts returned to factory, and prepay charges.

PRICE LIST OF BRUSH PARTS

Model "D" Parts

BODY AND FRAME PARTS.

Part No.	Price Each	DESCRIPTION	No. Per Car	
			D24	D26
1635-D	\$24.00	Body		1
1646-D	28.80	Body Seat—Upholstered (without cushions).....		1
	38.40	Body Seat—Painted and Upholstered with cushions.....		1
	4.80	Body Seat Cushions (Right).....		1
	4.80	Body Seat Cushions (Left).....		1
	62.40	Body Painted and Upholstered with seat and cushions.....		1
1647-C	24.00	Body Seat—Single Rumble—Upholstered.....		1
1722-D	24.00	Body—Roadster		1
1662-C	1.50	Lamp (gas) Fork.....	2	2
1620-D	30.00	Radiator	1	
	30.00	Radiator		1
1618-C	.42	Radiator Apron	1	1
969	.25	Radiator Drain Cock.....	1	1
1631-B	.50	Radiator Filler Cap.....	1	1
1619-B	.24	Radiator Hinge	2	2
1617-B	.30	Radiator Tie Rod.....	1	
1736-B	.30	Radiator Tie Rod.....		1
853-A	.06	Radiator Hinge Pin.....	2	2
785-D	2.82	Radius Rod Bracket—Front.....	2	2
RR5026	2.82	Radius Rod Bracket—Rear.....	2	2
RR5027	.30	Radius Rod Bracket Bushing.....	2	2
829-C	1.80	Radius Rod Bracket Tube.....	2	2
DR5047	.06	Radius Rod Bracket Tube Nut.....	2	2
1882-B	.30	Radius Rod Bracket Block, Front, Right, 60-in. Tread.....	1	1
1883-B	.30	Radius Rod Bracket Block, Front, Left, 60-in. Tread.....	1	1
1884-B	.30	Radius Rod Bracket Block, Rear, Right, 60-in. Tread.....	1	1
1885-B	.30	Radius Rod Bracket Block, Rear, Left, 60-in. Tread.....	1	1
RR5032	.24	Radius Rod Spider—Front.....	2	2
RR5033	.24	Radius Rod Spider—Rear.....	2	2
RR5038	.12	Radius Rod Washer—Inside.....	4	4
RR5039	.12	Radius Rod Washer Outside—Front.....	2	2

Order parts for repairs or renewals by number, and name in full and give the number of your motor, which will be found stamped immediately on top of the cylinder.

MODELS "D", "E", "F" AND "LIBERTY"

BODY AND FRAME PARTS.

Part No.	Price Each	DESCRIPTION	No. Per Car	
			D24	D26
RR5040	\$.12	Radius Rod Washer Outside—Rear	2	2
RR5042	.12	Radius Rod Washer Plate—Front.....	2	2
RR5043	.12	Radius Rod Washer Plate—Rear.....	2	2
	2.10	Engine Pan	1	1
1608-D	6.00	Fender—Front—Right	1	1
1609-D	6.00	Fender—Front—Left	1	
1610-D	5.40	Fender—Rear—Right	1	
1611-D	5.40	Fender—Rear—Left	1	
	.12	Fender Fastener, Eye Bolt.....	6	
	.06	Fender Fastener, Eye Bolt Nut.....	6	
1613-D	.84	Fender Iron—Front—Right	1	
1614-D	.84	Fender Iron—Front—Left	1	
1615-C	.84	Fender Iron—Rear—Right	1	
1616-C	.84	Fender Iron—Rear—Left	1	
1743	6.00	Fender—Front—Right		1
1744	6.00	Fender—Front—Left		1
1745	5.40	Fender—Rear—Right		1
1745	5.40	Fender—Rear—Left		1
1748	.84	Fender Iron—Front—Right		1
1749	.84	Fender Iron—Front—Left		1
1750	.84	Fender Iron—Rear—Right		1
1751	.84	Fender Iron—Rear—Left		1
945-B	.36	Heel Board Catch.....	2	
1664-D	12.00	Hood	1	
1666-C	.90	Hood Shelf—Right Hand.....	1	
1667-C	.90	Hood Shelf—Left Hand.....	1	
1732-D	15.00	Hood		1
1733-D	.90	Hood Shelf—Right Hand.....		1
1734-D	.90	Hood Shelf—Left Hand.....		1
1888-C	.90	Hood Shelf—Right Hand—60-in. Tread.....	1	
1889-C	.90	Hood Shelf—Left Hand—60-in. Tread.....	1	
1890-D	.90	Hood Shelf—Right Hand—60-in. Tread.....		1
1891-D	.90	Hood Shelf—Left Hand—60-in. Tread.....		1

Be sure to put your name and motor number on parts returned to factory and prepay charges.

PRICE LIST OF BRUSH PARTS

BODY AND FRAME PARTS.

Part No.	Price Each	DESCRIPTION	No. Per Car	
			D24	D26
959-C	\$.24	Hood Fastener—Left Hand	2	2
960-C	.24	Hood Fastener—Right Hand.....	2	2
961-B	.24	Hood Fastener Bushing.....	4	4
963-A	.06	Hood Fastener Spring.....	4	4
1665-D	1.80	Hood Ledge (on Dash).....	1	1
FR5070	.18	Lamp (oil) Bracket—Front.....	2	2
953-B	.48	Lamp (oil) Bracket—Rear.....	1	
	.48	Lamp (oil) Bracket—Rear.....		1
1660-C	.24	Lamp (gas) Bracket—Right Hand.....	1	1
1661-C	.24	Lamp (gas) Bracket—Left Hand.....	1	1
793-B	.30	Body Bumper (Rubber).....	4	
1628-C	.78	Body Corner Bracket No. 1.....	2	
1629-C	.78	Body Corner Bracket No. 2.....	2	
1656-C	1.20	Cross Member—Front—56-in. Tread.....	1	
1657-C	1.20	Cross Member—Rear—56-in. Tread.....	1	
1686-C	1.20	Cross Member—Front—60 in. Tread.....	1	
1887-C	1.20	Cross Member—Rear—60in. Tread.....	1	
1640-D	5.40	Dash	1	
1601-C	.48	Dash Support Bracket—Right Hand.....	1	
1602-C	.48	Dash Support Bracket—Left Hand.....	1	
1740-D	5.40	Dash Roadster	1	
1621-D	1.20	Running Board	1	
1623-D	.42	Running Board Cross Bar.....	2	2
1893-D	.48	Running Board Cross Bar, 60-in. Tread.....	2	2
1625-A	.06	Running Board Spacer.....	4	4
1626	.18	Running Board Hanger.....	4	4
1654-D	1.62	Side Bar—Right	1	
1655-D	1.62	Side Bar—Left	1	
497-C	1.50	Spring—Light	4	4
1847-C	1.75	Spring, Heavy	4	4
728-D	.90	Spring Bracket—Right	2	2
1848-D	.90	Spring Bracket—Right—Heavy	2	2
729-D	.90	Spring Bracket—Left	2	2
1849-D	.90	Spring Bracket—Left—Heavy	2	2

Order parts for repairs or renewals by number, and name in full and give the number of your motor, which will be found stamped immediately on top of the cylinder.

MODELS "D", "E", "F" AND "LIBERTY"

BODY AND FRAME PARTS.

Part No.	Price Each	DESCRIPTION	No. Per Car	
			D24	D26
1603-C	\$0.90	Spring Post, Nut and Dust Cap.....	4	4
1630-C	.90	Truss Rod Frame.....	2	2
746-C	.60	Truss Rod Bracket.....	1	1
621-B	.18	Truss Rod Washer Plate.....	2	2

AXLE AND WHEEL PARTS.

778-C	2.40	Axle—56-in. Tread (State Color).....	2	2
1030-C	2.40	Axle—60-in. Tread (State Color).....	2	2
780-B	.60	Truss Rod—56-in. Tread.....	2	2
1032-B	.72	Axle Truss Rod—60-in. Tread.....	2	
558-B	.24	Axle Strut—Front	2	
557-B	.30	Axle Strut—Rear	2	2
	.06	Balls 3/8 in.—High Duty.....	44	44
	.06	Balls 9/16 in.—High Duty.....	44	44
1496-B	.48	Ball Race—Large for 9/16 in. Balls.....	4	4
1497-B	.42	Ball Race—Small for 3/8 in. Balls.....	4	4
704-B	.18	Ball Retainer—Large for 9/16 in. Balls.....	4	4
708-B	.12	Ball Retainer—Small for 3/8 in. Balls.....	4	4
723-A	.60	Cone Spindle—Large	4	4
724-A	.54	Cone Spindle—Small	4	4
1483-A	.30	Cone Spindle Adjusting Nut.....	4	4
	6.30 ^{5.25}	Drive Chain 1/2".....	1	1
1495-B	.12	Dust Cap	4	4
706-B	.06	Dust Cap Felt.....	4	4
	8.40	Hub—Including Balls, Ball Races, Retainers, Dust Cap and Felt (specify front or rear)		
1489-B	1.08	Hub Cap	4	4
1494-C	.60	Hub Flange	4	4
776-D	1.80	Radius Rod	4	4
777-C	.30	Radius Rod Tension Member.....	4	4

Be sure to put your name and motor number on parts returned to factory and prepay charges.

PRICE LIST OF BRUSH PARTS

AXLE AND WHEEL PARTS.

Part No.	Price Each	DESCRIPTION	No. Per Car	
			D24	D26
1485-D	\$4.20	Skein—Front—Right Hand	1	1
1486-D	4.20	Skein—Front—Left Hand	1	1
1487-D	3.30	Skein—Rear—Right Hand	1	1
1488-D	3.30	Skein—Rear—Left Hand	1	1
RA5040	.06	Skein Adjusting Screw	4	4
M8	.05	Skein Adjusting Screw Nut	4	4
RA5019	.12	Skein Clamping Bolt	4	4
736-D	2.40	Skein Sleeve—Right Hand	1	1
737-D	2.40	Skein Sleeve—Left Hand	1	1
N-8	.05	Skein Clamping Bolt Nut	4	4
RA5021	.05	Skein Clamping Bolt Washer	4	4
	6.78	Spindle—Left Rear—With Skein Sleeve and Brake Band Support	1	1
	6.78	Spindle—Right Rear—With Skein Sleeve and Brake Band Support	1	1
1482-C	3.30	Spindle—Rear	2	2
2452-B	5.40	Sprocket Wheel—50 teeth ½ in. thick	2	2
1490-C	2.40	Steering Tie Rod, 56-in. Tread	1	1
	2.70	Steering Tie Rod, 60-in. Tread	1	1
772-B	.36	Steering Tie Rod Bolt	2	2
725-A	.06	Steering Tie Rod Bolt Nut	2	2
1481-D	4.80	Steering Arm—Right Hand	1	1
710-B	3.00	Steering Arm—Left Hand	1	1
718-A	.30	Steering Arm Bushing—Bronze	2	2
	4.80	Steering Knuckle and Spindle—Right Hand	1	1
	3.90	Steering Knuckle and Spindle—Left Hand	1	1
722-B	.48	Steering Knuckle Bolt	2	2
725-A	.06	Steering Knuckle Bolt Nut	2	2
719-A	.18	Steering Knuckle Bushing (Steel)	4	4
	12.00	Wheel—Rear—With hub and rim 28 in.	2	2
	17.40	Wheel—Rear—With hub, rim and sprocket, 28 in.	2	2
	12.00	Wheel—Front—With hub and rim, 28 in.	2	2
	12.00	Wheel—Front—With hub and rim, 30 in.	2	2
	12.00	Wheel—Rear—With hub and rim, 30 in.	2	2
	17.40	Wheel—Rear—With hub, rim and sprocket, 30 in.	2	2

Order parts for repairs or renewals by number, and name in full, and give the number or your motor, which will be found stamped immediately on top of the cylinder.

MODELS "D", "E", "F" AND "LIBERTY"

MOTOR PARTS.

Part No.	Price Each	DESCRIPTION	No. Per Car	
			D24	D26
	\$114.00	Motor, complete	1	1
930-C	.78	Breather, Crank Case	1	1
931-C	.30	Breather Screen	1	1
1221-B	1.20	Cam Gear	1	1
	1.92	Cam Gear and Shaft	1	1
K5	.05	Cam Gear Key	1	1
EN5035	.36	Cam Roller	2	2
EN5036	1.38	Cam Roller Bracket—Intake	1	1
EN5037	1.38	Cam Roller Bracket—Exhaust	1	1
1222-B	.30	Cam Roller Retainer	1	1
S5062	.05	Cam Roller Screw	2	2
1238-B	.60	Cam Shaft	1	1
	7.80	Connecting Rod, Complete, including bushing, caps, oil scoop, hinge pin, screw and washer	1	1
1201-D	4.80	Connecting Rod	1	1
EN5042	.60	Connecting Rod Bushing (Piston Pin)	1	1
EN5056	.54	Connecting Rod Bushing, Lower Half (Crank Pin)	1	1
1243-B	.54	Connecting Rod Bushing, Upper Half (Crank Pin)	1	1
EN5049	.18	Connecting Rod Screw	1	1
EN5046	.12	Connecting Rod Screw Nut	1	1
EN5051	.06	Connecting Rod Screw Washer	1	1
902-C	.90	Counterbalance (on Crank)	2	2
903-A	.06	Counterbalance Stud	2	2
904-A	.06	Counterbalance Stud Nut	2	2
	10.80	Counterbalance Gear, complete, including parts as follows	1	1
1293-C	4.20	Counterbalance Gear	1	1
1298-B	.60	Counterbalance Gear Adjusting Sector	1	1
1241-A	.06	Counterbalance Gear Adjusting Sector Clamping Stud	1	1
1294-B	.60	Counterbalance Gear Ball Race	2	2
	.05	Counterbalance Gear Balls, 3/8 in. high duty	22	22
1296-B	.48	Counterbalance Gear Stud	1	1
1297-A	.30	Counterbalance Gear Stud Cone—Narrow	1	1
724-A	.36	Counterbalance Gear Stud Cone—Wide	1	1
1483-A	.30	Counterbalance Gear Stud Cone Adjusting Nut	1	1
469-A	.12	Counterbalance Gear Stud Nut	1	1
1250	2.40	Commutator, complete, including parts as follows	1	1
1251-A	.06	Commutator Binding Post	1	1

Be sure to put your name and motor number on parts returned to factory and prepay charges.

PRICE LIST OF BRUSH PARTS

MOTOR PARTS.

Part No.	Price Each	DESCRIPTION	No. Per Car	
			D24	D26
1252-A	\$0.06	Commutator Binding Post Nut.....	2	2
1253-B	.36	Commutator Body	1	1
1254-A	.30	Commutator Body Bushing.....	1	1
1255-B	.30	Commutator Cover	1	1
1259-A	.30	Commutator Pull Rod Block.....	1	1
1260-A	.18	Commutator Pull Rod Bushing.....	1	1
570-B	.12	Commutator Spring	1	1
1264-A	.06	Commutator Spring Pin.....	2	2
1203E-D	22.20	Crank Case	1	1
	25.20	Crank Case with Studs and Bearing Bushing.....	1	1
EN5010	1.62	Crank Case Bearing Bushing.....	1	1
936-A	.42	Crank Case Oil Check Valve.....	1	1
1280-C	.18	Crank Case Hand Hole Cover.....	1	1
1247-B	.06	Crank Case Hand Hole Cover Gasket.....	1	1
1281-A	.06	Crank Case Stud.....	4	4
1274-A	.06	Crank Case Oil Tube.....	1	1
1204-D	14.40	Crankshaft	1	1
	18.00	Crankshaft with counterbalances and studs.....	1	1
1211-C	1.80	Crankshaft Gear	1	1
1212-A	.24	Crankshaft Gear Pin.....	1	1
EN5057	.18	Crankshaft Washer—Narrow	1	1
	21.60	Cylinder Complete, including studs, nuts, heads, valve caps, valves, springs, washers, collars, drain cock, gaskets, discharge and intake pipe and water jacket plug,.....	1	1
EN5061	.18	Crankshaft Washer—Wide	1	1
1206-D	15.60	Cylinder	1	1
EN5066	.24	Cylinder Drain Cock.....	1	1
EN5068	.06	Cylinder Gasket	1	1
398-B	1.02	Cylinder Head	1	1
EN5072	.42	Elbow Binder	1	1
1207-C	12.00	Fly Wheel	1	1
EN5077	.12	Fly Wheel Key.....	2	2
1217-A	.18	Fly Wheel Nut.....	1	1
1242-B	.18	Fly Wheel Hub Cover.....	1	1
1283-B	.12	Fly Wheel Hub Cover Gasket.....	1	1
1286-A	.05	Fly Wheel Hub Cover Screw.....	4	4

Order parts for repairs or renewals by number, and name in full and give the number of your motor, which will be found stamped immediately on top of the cylinder.

MODELS "D", "E", "F" AND "LIBERTY"

MOTOR PARTS.

Part No.	Price Each	DESCRIPTION	No. Per Car	
			D24	D26
EN5125	\$4.80	Piston	1	1
EN5126	.72	Piston Pin	1	1
EN5127	.06	Piston Pin Plug.....	1	1
EN5128	.48	Piston Ring	3	3
1210-D	7.86	Side Plate	1	1
	8.40	Side Plate for Magneto.....	1	1
EN5140	1.26	Side Plate Bearing Bushing.....		
1261-A	.12	Side Plate Commutator Retaining Spring.....	1	1
1348-A	.06	Side Plate Commutator Retaining Spring and Screw.....	1	1
1229-B	.60	Side Plate Cover.....	1	1
1248-B	.06	Side Plate Cover Gasket.....	1	1
1275-A	.06	Side Plate Oil Plug.....	1	1
1241-A	.06	Side Plate Stud.....	7	
N-6	.05	Side Plate Stud Nut.....	7	7
1249-B	.06	Side Plate Gasket.....	1	1
	13.20	Side Plate Assembled, complete, including above items; also cam gear parts and valve cam and pin.....	1	1
1239-A	.42	Spark Cam	1	1
1240-A	.05	Spark Cam Set Screw.....	1	1
1230-D	1.50	Starting Crank	1	1
1231-D	2.40	Starting Crank Bracket.....	1	1
1232-A	.30	Starting Crank Bushing.....	1	1
1233-A	.12	Starting Crank Bushing Set Screw.....	1	1
M-6	.05	Starting Crank Bushing Set Screw Check Nut.....	1	1
916-A	.12	Starting Crank Pin.....	1	1
187-A	.06	Starting Crank Spring.....	1	1
1234-A	.06	Starting Crank Washer.....	2	2
1235-B	.96	Starting Ratchet	1	1
P4125	.10	Starting Ratchet Pin.....	1	1
	6.60	Starting Crank, complete, including above parts.....		
1237-A	1.08	Valve Cam	1	1
P-2112	.05	Valve Cam Pin.....	1	1
265-B	.42	Valve Cam Relief.....	1	1
263-B	.54	Valve Cap Spark Plug.....	1	1
289-A	.06	Valve Cap Gasket.....	2	2
	.48	Valve and Stem.....	2	2

Be sure to put your name and motor number on parts returned to factory, and **prepay charges.**

PRICE LIST OF BRUSH PARTS

MOTOR PARTS.

Part No.	Price Each	DESCRIPTION	No. Per Car	
			D24	D26
509-B	\$0.90	Valve Pusher	2	2
EN-5174	.06	Valve Spring	2	2
1271-A	.18	Valve Stem Collar.....	2	2
EN5175	.06	Valve Stem Washer.....	2	2
1270-B	.12	Water Inlet Pipe.....	1	1
	.15	Water Inlet Hose, 1 in. I. D. 6 in. L.....	1	1
	.05	Water Inlet Hose Clamps.....	2	2
1269-A	.30	Water Outlet Pipe.....	1	1
	.25	Water Outlet Hose, 1¼ in. I. D., 5¾ in. long.....	1	1
	.10	Water Outlet Hose Clamps.....	2	2

LUBRICATION OF THE MOTOR.

There should be at all times not less than one-half of an inch of motor oil at the bottom of the crank case. Inspection should be made from time to time to ascertain whether or not the lubricator is operating satisfactorily and delivering the required amount of oil. Do not use anything but the best grade of motor or gas engine oil of high fire test. Use oil freely, but not excessively or wastefully. From ten to fourteen drops a minute from the dash oiler should be sufficient for the engine lubrication. See that all connections at the lubricator are tight, and free from any leakage.

TRANSMISSION.

	\$114.00	Transmission, complete		
1353-B	1.80	Adjusting Nut	1	1
1349-A	.12	Adjusting Nut Set Screw.....	1	1
M-7	.05	Adjusting Nut Check Nut.....	1	1
RM5004	.06	Balls, ½ in.....	9	9
1404-A	.12	Balls, ¾ in.....	14	14
1356-B	2.10	Ball Race—Large 35/16 in.....	1	1
421-B	1.92	Ball Race—Small—External	1	1

Order parts for repairs or renewals by number, and name in full and give the number of your motor, which will be found stamped immediately on top of the cylinder.

MODELS "D", "E", "F" AND "LIBERTY"

TRANSMISSION PARTS.

Part No.	Price Each	DESCRIPTION	No. Per Car	
			D24	D26
423-B	\$1.50	Ball Race—Small—Internal	1	1
646-B	.06	Ball Race Shim Washer.....	1	1
2532-B	7.80	Bevel Pinion	1	1
430-C	2.70	Bevel Pinion Shaft.....	1	1
463-A	.10	Bevel Pinion Key.....	1	1
1375-D	2.10	Control Lever.....	1	1
1377-D	1.56	Control Lever Bracket.....	1	1
1627-A	.18	Control Lever Bracket Grease Cup.....	1	1
1376-A	.06	Control Lever Cone Screw.....	2	2
1378-C	.84	Control Shaft	1	1
1381-A	.30	Control Shaft Collar.....	1	1
1380-C	.96	Control Shaft Hanger.....	1	1
1382-C	.30	Control Shaft Lever.....	1	1
1383-A	.12	Control Shaft Lever Set Screw.....	1	1
725-A	.06	Control Shaft Nut.....	1	1
1379-A	.06	Control Shaft Washer.....	1	1
1384-C	2.82	Control Tube	1	1
1385-A	.18	Control Tube Bushing.....	2	2
1386-C	.60	Control Tube Lever.....	1	1
1332-C	2.70	Coupling Shaft	1	1
1338-A	.54	Coupling Slide Block.....	4	4
1340	2.70	Drag Link Complete.....	2	2
1341-B	.48	Drag Link Adjustable Yoke Rod End.....	2	2
1342-B	.42	Drag Link Solid Yoke Rod End.....	2	2
1344-A	.06	Drag Link Pin.....	3	3
1345-A	.30	Drag Link Pin (Clutch Release).....	1	1
1331-C	2.40	Drive Shaft	1	1
	3.66	Drive Shaft, Complete.....	1	1
422-A	.12	Drive Shaft Key.....	2	2
225-A	.06	Drive Shaft Thrust Disc.....	1	1
1369-A	.24	Drive Shaft Collar.....	1	1
408-B	.90	Fork	1	1
TR5033	.24	Fork Journal	1	1
TR5036	.06	Fork Pin	2	2

Be sure to put your name and motor number on parts returned to factory and prepay charges.

PRICE LIST OF BRUSH PARTS

Part No.	Price Each	DESCRIPTION	No. Per Car	
			D24	D26
443-A	\$.12	Fork Set Screw.....	1	1
420-B	.90	Gear (Drive Shaft).....	1	1
428-A	.24	Gear Bushing	1	1
425-A	.12	Gear Pin	1	1
414-C	3.00	Gear (Internal)	1	1
463-A	.12	Gear Key	1	1
TR100	.06	Gear Washer	1	1
1361-B	.78	Gear (Low Speed).....	1	1
1362-B	.42	Gear Bushing (Low Speed).....	1	1
419-B	2.40	Gear (Planetary)	4	4
427-B	.24	Gear Bushing (Planetary).....	4	4
1351-D	4.26	Gear Mount	1	1
1368-B	.24	Gear Mount Shaft.....	4	4
406-C	1.80	High Speed Clutch Collar.....	1	1
458-B	1.92	High Speed Clutch Collar Ball Thrust Bearing.....	1	1
433-A	.12	High Speed Clutch Collar Control Pin.....	2	2
426-B	.30	High Speed Clutch Collar Nut.....	1	1
460-B	.60	High Speed Clutch Collar Shoe.....	2	2
438-C	2.40	High Speed Clutch Mount.....	1	1
404-C	1.32	High Speed Clutch Sleeve.....	1	1
431-A	.18	High Speed Clutch Pressure Roller.....	2	2
432-A	.18	High Speed Clutch Pressure Roller Stud.....	2	2
405-B	.60	High Speed Clutch Thrust Ring	1	1
413-B	.72	High Speed Clutch Disc (Bronze)	3	3
437-B	.54	High Speed Clutch Disc (Steel)	4	4
1387-C	.66	High Speed Lever	1	1
1388-A	.12	High Speed Lever Pin	1	1
1389-B	.72	High Speed Lever Shaft	1	1
1390-A	.06	High Speed Lever Shaft Washer	1	1
939-B	.18	High Speed Spring	1	1
1323-B	.06	High Speed Spring Loop	1	1
1354-D	10.20	Housing—Front End	1	1
1363-B	1.20	Housing Bushing—Front End.....	1	1
1347-A	.06	Housing Bushing—Front End—Set Screw.....	1	1
1364-B	.36	Housing Cover Plate—Large.....	1	1

Order parts for repairs or renewals by number, and name in full and give the number of your motor, which will be found stamped immediately on top of the cylinder.

MODELS "D", "E", "F" AND "LIBERTY"

TRANSMISSION PARTS.

Part No.	Price Each	DESCRIPTION	No. Per Car	
			D24	D26
T4100	\$.06	Housing Cover Stud.....	4	4
452-A	.05	Housing Stud Wing Nut.....	4	4
EN5147	.06	Housing Drain Plug.....	1	1
1397-A	.24	Housing Dust Cap.....	1	1
1398-A	.06	Housing Dust Cap Ring.....	1	1
1399-B	.66	Housing Hanger.....	1	1
1350-A	.24	Housing Hanger Pin.....	1	1
1373-C	.72	Housing Side Plate.....	1	1
1372-C	.06	Housing Side Plate Gasket.....	1	1
T4100	.06	Housing Side Plate Stud.....	4	4
1405-A	.06	Housing Stud (Rear).....	4	4
1355-D	6.60	Housing—Rear End.....	1	1
	42.00	Housing—Rear End—Assembled.....	1	1
1365-B	.12	Housing Cover Plate—Small.....	1	1
1371-B	.06	Housing Gasket.....	1	1
1392-C	1.20	Interlocker Lever—Inside.....	1	1
1393-C	2.10	Interlocker Lever—Outside.....	1	1
1383-A	.06	Interlocker Lever Set Screw.....	1	1
1394-B	.12	Interlocker Lever Spring.....	2	2
1359-C	.72	Low and Reverse Disc (Bronze).....	4	4
1360-C	.42	Stationary Disc (Cast Iron).....	2	2
1366-C	.66	Low and Reverse Lever—Inside.....	1	1
1396-B	.48	Low and Reverse Lever—Outside.....	1	1
1358-C	2.40	Low and Reverse Ring—Cast Iron.....	1	1
1370-B	.24	Low and Reverse Shifting Pin.....	1	1
1320-A	.36	Low and Reverse Stud.....	3	3
1321-A	.18	Low and Reverse Stud Roller.....	3	3
1322-A	.06	Low and Reverse Stud Washer.....	3	3
1352-D	2.10	Low Speed Spider.....	1	1
1324-B	1.50	Support Member.....	1	1
1325-D	1.80	Universal Joint Housing.....	1	1
1328-A	.12	Universal Joint Housing Key.....	1	1
1327-A	.12	Universal Joint Housing Screw.....	4	4

Be sure to put your name and motor number on parts returned to factory and prepay charges.

PRICE LIST OF BRUSH PARTS

Part No.	Price Each	DESCRIPTION	No. Per Car	
			D24	D26
RM5004	\$.06	Ball, 1/2 in.....	10	10
1404-A	.12	Balls, 3/4 in.....	13	13
RM5014	1.80	Ball Race, 2 1/2 in. for 1/2 in. balls.....	1	1
1403-B	2.16	Ball Race, 4 1/4 in. for 3/4 in. balls.....	1	1
646-B	.06	Ball Race Shim Washer.....	1	1
1402-C	7.20	Gear, 24 teeth—Driving.....	1	1
DG4014	4.20	Gear, 22 teeth.....	2	2
638-B	3.60	Gear, 12 teeth—Pinion.....	2	2
DG4017	3.60	Gear Mount.....	1	1
DG4018	.24	Gear Mount Cone.....	1	1
DG4019	.06	Gear Mount Washer.....	1	1
1401-D	6.30	Housing.....	1	1
1406-B	.06	Housing Gasket.....	1	1
TR5085	.06	Housing Oil Plug.....	1	1
1405-A	.06	Housing Stud.....	4	4
539-B	.96	Housing Support Tube—Long.....	1	1
1037-B	1.08	Housing Support Tube—Long—Wide Tread.....	1	1
540-B	.84	Housing Support Tube—Short.....	1	1
1038-B	.96	Housing Support Tube—Short—Wide Tread.....	1	1
DG5057	.36	Housing Support Tube Collar.....	2	2
S6200	.06	Housing Support Tube Collar Screw.....	2	2
390-A	.06	Housing Support Tube Collar Set Screw.....	4	4
272-C	2.70	Housing End.....	1	1
S7250	.06	Housing End Clamp Screw.....	1	1
318-A	.06	Housing End Lock Screw.....	1	1
DG4031	.06	Housing End Lock Screw Washer.....	1	1
830-C	2.40	Jack Shaft—Long.....	1	1
1041-C	2.70	Jack Shaft—Long—Wide Tread.....	1	1
831-C	1.80	Jack Shaft—Short.....	1	1
1042-C	2.10	Jack Shaft—Short—Wide Tread.....	1	1
832-B	1.20	Jack Shaft Bearing Bushing.....	2	2
541-A	.06	Jack Shaft Collar.....	2	2
834-A	.12	Jack Shaft Collar Felt Washer.....	2	2
K-22	.05	Jack Shaft Collar Key.....	2	2
835-C	1.80	Jack Shaft Sleeve.....	2	2

Order parts for repairs or renewals by number, and name in full, and give the number of your motor, which will be found stamped immediately on top of the cylinder.

MODELS "D", "E", "F" AND "LIBERTY"

DIFFERENTIAL PARTS.

Part No.	Price Each	DESCRIPTION	No. Per Car	
			D24	D26
837-B	\$.12	Jack Shaft Sleeve Cup.....	2	2
838-A	.06	Jack Shaft Sleeve Key.....	4	4
	16.20	Jack Shaft Complete, including above parts; also Jack Shaft Sprockets.....		
287-A	.60	Pinion Shaft	1	1
	.06	Pinion Shaft Pin.....	2	2
839-B	\$1.56	Sprocket—11 Teeth—Jack Shaft.....	1	
840-B	1.92	Sprocket—13 Teeth—Jack Shaft.....	2	
843-B	2.28	Sprocket—14 Teeth—Jack Shaft.....	2	
841-B	2.52	Sprocket—15 Teeth—Jack Shaft.....	2	
842-B	2.88	Sprocket—16 Teeth—Jack Shaft.....	2	
844-A	.06	Sprocket Pin	2	2
	54.00	Differential Complete	1	1

STEERING GEAR PARTS.

1588-D	.60	Bracket	1	
1561-A	1.80	Casing with head.....	1	
1551-C	1.80	Connecting Rod, including Yoke and Pin.....	1	
1897-C	2.40	Steering Connecting Rod, including Yoke and Pin, Wide Tread.....	1	1
1552-B	.18	Connecting Rod Cap.....	4	4
SG5044	.12	Connecting Rod Pin.....	2	2
1554-C	.72	Connecting Rod Yoke.....	2	2
603-B	.60	Cover	1	1
609-A	.24	Cover Bushing	1	1
604-B	.06	Cover Gasket	1	1
SG5015	.36	Eccentric	1	1
P4175	.05	Eccentric Pin	1	1
1563-B	1.32	Gear—Internal	1	1
1565-C	3.00	Gear Shaft	1	1
SG5080	.30	Gear Bushing	1	1
K-21	.15	Gear Shaft Key.....	1	1
	4.20	Hand Wheel Complete.....	1	
	4.20	Hand Wheel Complete.....		1
SS5016	2.40	Hand Wheel Rim.....	1	1
SS5018	.96	Hand Wheel Spider.....	1	1
306-B	.42	Hand Wheel Hub with Dowel Pin.....	1	1
SS5022	.12	Hand Wheel Hub Nut.....	1	1

Be sure to put your name and motor number on parts returned to factory and prepay charges.

PRICE LIST OF BRUSH PARTS

Part No.	Price Each	DESCRIPTION	No. Per Car	
			D24	D26
788-D	\$3.30	Housing, including Studs.....	1	1
1559-D	1.20	Housing Brace	1	
T4100	.06	Housing Cover Stud.....	4	4
946-A	.06	Housing Stud—Upper	2	2
947-A	.06	Housing Stud—Lower	1	1
1556-D	1.38	Lever	1	1
S8150	.05	Lever Screw	1	1
SG5036	.96	Pinion (See Tail-607B).....	1	1
1562-A	.72	Shaft (Pinion)	1	
1782-A	1.32	Shaft (Steering Gear).....		1
1576-A	.54	Spark Lever—Commutator	1	
1577-B	.54	Spark Lever—Magneto		1
1566-B	1.14	Spark and Throttle Rod.....	2	2
69-A	.18	Spark and Throttle Rod Knob.....	2	2
563-A	.06	Spark and Throttle Rod Spring.....	2	2
315-A	.06	Spark and Throttle Rod Washer.....	2	2
1567-A	.06	Spark Push Rod.....	1	1
1573-A	.18	Spark Push Rod Coupling.....	1	1
	1.68	Tail Complete with Pinion.....	1	1
607-B	.72	Tail	1	1
SG5090	.12	Tail Slide	1	1
SG5091	.12	Tail Slide Pin.....	1	1
1575-B	.84	Throttle Lever	1	
1567-A	.12	Throttle Push Rod.....	1	1
1573-A	.18	Throttle Push Rod Coupling.....	1	1
1580	.30	Magneto Push Rod.....	1	1
1581-A	.12	Magneto Push Rod Bracket.....		1
1573-A	.06	Magneto Push Rod Coupling.....		1
BRAKE PARTS.				
	2.40	Band Complete with Ends and Linings.....	2	2
	1.50	Band with Ends.....	2	2
730-B	.12	Band Support	4	4
795-B	.90	Lining	2	2
1504-A	.12	Clutch Release Rod.....	1	1
591-A	.60	Clutch Release Rod Yoke.....	1	1

Order parts for repairs or renewals by number, and name in full, and give the number of your motor, which will be found stamped immediately on top of the cylinder.

MODELS "D", "E", "F" AND "LIBERTY"

BRAKE PARTS.

Part No.	Price	DESCRIPTION	No. Per Car	
			D24	D26
492-A	\$.06	Clutch Release Rod Yoke Pin.....	1	1
749-B	.12	Evener	1	1
750-C	.60	Evener Lever	2	2
1501-D	1.50	Foot Pedal	1	1
739-D	1.02	Foot Pedal Bracket.....	1	1
1502-C	.48	Foot Pedal Pawl.....	1	1
740-B	.60	Foot Pedal Stud.....	1	1
741-A	.12	Foot Pedal Stud Collar.....	1	1
1503-B	.12	Pull Rod—Long	1	1
797-B	.12	Pull Rod—Short	2	2
491-A	.72	Pull Rod Yoke.....	6	6
494-A	.24	Pull Rod Yoke Pin.....	6	6
751-B	.48	Shaft—Long	1	1
1033-B	.60	Shaft—Long—Wide Tread	1	1
752-B	.24	Shaft—Short	1	1
1034-B	.36	Shaft—Short—Wide Tread	1	1
BR5040	.60	Shaft Lever—Outside	2	2
322-A	.24	Shaft Collar	2	2
323-A	.10	Shaft Collar Screw.....	2	2
BR5051	.12	Spring	1	1
733-A	.30	Wedge	2	2
747-C	.96	Wedge Lever—Right Hand.....	1	1
747-C	.96	Wedge Lever—Left Hand.....	1	1
951-B	.18	Wedge Lever Hinge Pin.....	2	2
848-A	.06	Wedge Pin	2	2

CARBURETOR PARTS.

	10.50	Carburetor—Kingston	1	1
1532-A	.05	Carburetor Gasket	1	1
1534-C	.66	Gasoline Feed Pipe with Unions.....	1	
1708	.66	Gasoline Feed Pipe (Dash Tank) with Unions.....		1
2475-C	.90	Gasoline Feed Pipe (Rear Tank) with Unions.....		1
1709-A	.18	Gasoline Tank (Front) Tee.....		1
1712-A	.36	Gasoline Shut Off Cock—Rear.....		1
1540-D	7.80	Gasoline Tank (Dash).....	1	1
2476-D	18.00	Gasoline Tank (Rear).....		1

Be sure to put your name and motor number on parts returned to factory and prepay charges.

PRICE LIST OF BRUSH PARTS

Part No.	Price Each	DESCRIPTION	No. Per Car	
			D24	D26
CARBURETOR PARTS.				
822-B	\$0.60	Gasoline Tank Filler Cap—Front.....	1	1
	.60	Gasoline Filler Cap—Rear.....		1
1541-C	.60	Gasoline Tank Setting Chamber.....	1	1
EN5066	.30	Gasoline Tank Drain Cock.....	1	1
982-A	.36	Gasoline Shut Off Cock—Front.....	1	1
1537-C	2.40	Inlet Elbow.....	1	1
EN5083	.06	Inlet and Exhaust Elbow Gasket.....	2	2
1538-A	.06	Priming Wire.....	1	1
11	.50	Carburetor Needle Valve.....	1	1
1	.50	Carburetor Float.....	1	1
3	.50	Carburetor Gasoline Valve.....	1	1
LUBRICATION PARTS.				
1464	.72	Lubricator Feed Pipe and Nut.....	1	1
	4.80	Lubricator Tank Complete with Dash Oiler.....	1	1
1481-D	2.40	Lubricator Tank.....	1	1
874-B	.60	Lubricator Tank Filler Cap.....	1	1
	3.00	Dash Sight Feed Oiler.....	1	1
862	.24	Dash Sight Feed Oiler Glass—Long.....	1	1
863	.12	Dash Sight Feed Oiler Glass—Short.....	1	1
	.06	Dash Sight Feed Oiler Washers (Cork).....	5	5
624-A	.24	Steering Knuckle Oiler.....	2	2
1627-A	.36	Radius Rod Bracket Grease Cups.....	4	4
624-A	.24	Axle Tie Rod Oiler.....	2	2
624-A	.24	Transmission Control Shaft Oiler.....	1	1
1407-A	.54	Jack Shaft Sleeve Grease Cup.....	2	2
1627-A	.36	Foot Pedal Grease Cup.....	1	1
624-A	.24	Brake Wedge Hinge Pin Oiler.....	2	2
627-A	.18	Control Lever Bracket Grease Cup.....	1	1
627-A	.18	Steering Gear Housing Grease Cup.....	1	1
IGNITION PARTS.				
	.20	Battery—Dry Cells.....	8	
	.35	Battery Wire Primary, 90".....		
	.25	Battery Wire to Ground, 68".....		

Order parts for repairs or renewals by number, and name in full, and give the number of your motor, which will be found stamped immediately on top of the cylinder.

MODELS "D", "E", "F" AND "LIBERTY"

Part No.	Price Each	DESCRIPTION	IGNITION PARTS.	
			No. Per Car D24	D26
	\$.25	Battery Wire to Coil, 68".....		
	.50	Battery Wire, Secondary, 47".....		
	.25	Battery Wire to Commutator, 54".....		
	.05	Battery Coil Cell Connections.....		
	.10	Battery Terminal.....		
Fr5063	.30	High Tension Wire Support.....	1	1
	2.00	Dash Switch.....	1	
	40.00	Magneto Bosch.....	1	1
1285-C	.36	Magneto Bracket.....	1	1
1284-A	.24	Magneto Coupling.....	1	1
1227-A	.30	Magneto Gear Shaft Flange.....	1	1
1228-A	.42	Magneto Shaft Flange.....	1	1
1224-A	.48	Magneto Gear.....	2	2
1225-A	.24	Magneto Gear Shaft.....	2	2
1226-A	.18	Magneto Gear Shaft Collar.....	1	1
	2.70	Magneto Switch.....		1
2217-D	.60	Magneto Pan.....		1
To equip D-24 Car with Magneto requires above parts, also Side Plate 1210-D and Intake Valve Cap No. 263-B.				
	12.00	Coil Comp.		
	.15	Coil Key.....		
	10.00	Coil Unit.....		
	2.00	Coil Box.....		
	.50	Coil Box Lid.....		
	.90	J. B. Vibrator Spring.....		
	.90	J. B. Cross Bar.....		

MUFFLER PARTS.

1448-C	.60	Exhaust Deflector.....	1	1
1455-B	.18	Exhaust Deflector Support.....	1	1
1441-B	.48	Exhaust Elbow.....	1	1
1442-C	1.02	Exhaust Pipe.....	1	1
1446-B	.24	Muffler Cut-out Lever.....	1	1
1447-A	.12	Muffler Cut-out Spring.....	1	1
1450-C	.24	Muffler Cut-out Pedal.....	1	1
1451-A	.18	Muffler Cut-out Pedal Bracket.....	1	1
1445-B	.24	Muffler Cut-out Valve.....	1	1
	6.00	Muffler Complete.....	1	1

Be sure to put your name and motor number on parts returned to factory and prepay charges.